



Installation Guide for the Avaya™ IP Telephone Power Adapter

Comcode 700276611
August 2003

The enclosed device is used to allow the Avaya™ IP 4620 and IP 4602SW Telephones to be recognized and powered by Catalyst® power blades.

INSTALLATION:

Proper installation is necessary to ensure the unit operates correctly.

1. Set the switch on the bottom of the IPTPA as follows:

	Catalyst® 6509	Catalyst® 4006
IP 4602, IP 4602SW	1	3
IP 4620	1	2

2. Attach an RJ45-8 CAT 5 compliant cord (supplied with the IP 4600 Telephone) from the wall jack to the IP Telephone Power Adapter at the "LINE" side.
3. Attach the RJ45-8 CAT 5 compliant pigtail on the IP Telephone Power Adapter to the telephone line input jack.

NOTE:

Catalyst® is a registered trademark of Cisco Systems, Inc.

CAUTION:

This unit is not repairable.

Do not attempt to open or service this device.




Figure 1 – Adapter Switch